


Copying Specification into Job


Copying specifications from outside of Specsintact into Specsintact:

1. Place specification onto your hard or network drive. **(Where you will be able to relocate it.)**
2. Open Specsintact and double click open your Job. **(The one you want the spec copied into)**
3. Click File/Add Sections.
4. Click the **Browse** tab at the top of the dialog box.
5. Click the drop down box next to the word **Drive** and select the drive were you placed your specification (s) that you want copied.



Once you've found the specifications, they will show down in the Sections box. **(If they have the .sec extensions)**

6. Select the section(s) and click the Add Sections button.



Your sections are now added into your job!